



Afmontering af aktuator / demonter aktuator /
Monter av aktuator / Demounting the actuator
- VELA Tango 300E/310E

Afmontering af aktuator på VELA Tango 300E og VELA Tango 310E



Videoinstruktion:

vl1935.dk/105946